### FEED CONTROL VALVES UCF1G-01 / 03 / 04 (1/8, 3/8, 1/2) UCF2G-03 / 04 (3/8, 1/2) Gasket Mounting

### **Specifications / Model Number Designation**

### Up to 14 MPa (2030 PSI), 80 L/min (21.1 U.S.GPM)

These valves are the combination of flow control valve, a deceleration valve and a check valve and used mainly for controlling rapid traverse and feed cycles machine tools. Switching from rapid traverse to feed is made by a cam operation, and fine feed control is accomplished by dial rotation regardless of pressure and oil temperature variation. Rapid return is free of cam actuation.


Specifications						
Model Numbers	*1 Max. Flow L/min (U.S.GPM)	Metred Rar L/min (U Feed	ige	Max. Reversed Free Flow L/min (U.S.GPM)	Max. Operat- ing Pressure MPa (PSI)	Approx. Mass kg (lbs.)
UCF1G-01-4-A-*-11*	16 [12] (4.2 [3.2])	0.03-4				
UCF1G-01-4-B-*-11*	12 [8] (3.2 [2.1])	(.008-1.06) [0.05-4]				
UCF1G-01-4-C-*-11*	8 [4] (2.1 [1.06])	([.013-1.06])		20		1.6
UCF1G-01-8-A-*-11*	20 [12] (5.3 [3.2])	0.03-8		(5.3)		(3.5)
UCF1G-01-8-B-*-11*	16 [8] (4.2 [2.1])	(.008-2.1) [0.05-8] *2			14	
UCF1G-01-8-C-*-11*	12 [4] (3.2 [1.06])	([.013-2.1])				
UCF1G-03-4-*-10*	40 [40]	0.05-4 (.013-1.06)		40	(2030)	2.6
UCF1G-03-8-*-10*	(10.6 [10.6])	0.05-8 (.013-2.1)		(10.6)		(5.7)
UCF2G-03-4-*-10*	40 [40]	0.1-4 (.026-1.06)	0.05-4 (.013-1.06)	40		2.7
UCF2G-03-8-*-10*	(10.6 [10.6])	0.1-8 (.026-2.1)	0.05-4 (.013-1.06)	(10.6)		(6.0)
UCF1G-04-30-30*	80 [40]	0.1-22 (.026-5.8)		80		6.5 (14.3)
UCF2G-04-30-30*	(21.1 [10.6])	0.1-22 (.026-5.8)	0.1-17 (.026-4.5)	(21.1)		9.2 (20.3)



**FLOW** 







★ 1. The maximum flow rates are values with the deceleration valve and the flow control valve fully open. The values in [] are maximum flow rates with the deceleration valve fully open and the flow control valve fully closed.

★ 2. The values in [] are for pressures above 7 MPa (1020 PSI).


#### Model Number Designation

YUKEN

... ..

F-	UCF1	G	-01	-4	-A	-Е	-11	*
Special Seals	Series Number	Type of Mounting	Valve Size	Nominal Metred Flow L/min (U.S.GPM)	Deceleration Valve Max. Flow L/min (U.S.GPM)	Drain Connection	Design Number	Design Stan- dards
F-: UCF1: G: Special Single Gasket Seals for Feed Mounting Phosphate Control	G:	01	<b>4:</b> 4 (1.06) <b>8:</b> 8 (2.1)	<b>A:</b> 12 (3.2) <b>B:</b> 8 (2.1) <b>C:</b> 4 (1.06)	None: Internal Drain	11		
	Gasket Mounting	03	<b>4:</b> 4 (1.06) <b>8:</b> 8 (2.1)		E: External Drain	10	Refer to	
Ester Type Fluids			04	<b>30:</b> 30 (7.9)		None: External Drain	30	★1
(Omit if not required) UCF2: Double Feed Ga	<b>G:</b> Gasket	03	<b>4:</b> 4 (1.06) <b>8:</b> 8 (2.1)		None: Internal Drain E:External Drain	10	, , , , , , , , , , , , , , , , , , ,	
Control		ontrol Mounting -	04	<b>30:</b> 30 (7.9)		None: External Drain	30	

★ 1. Design Standards: None......Japanese Standard "JIS" and European Design Standard 90......N. American Design Standard



Synthetic fluids	Use phosphate ester or polyol ester fluid. When phosphate ester fluid is used, prefix "F-" to the mode number because the special seals (fluororubber) are required to be used.
Water containing fluids	Use water-glycol fluid.

Note: For use with hydraulic fluids other than those listed above, please consult your Yuken representatives in advance.

#### Recommended Viscosity and Oil Temperatures

Viscosity ranging between 15 - 400 mm<sup>2</sup>/s (77 - 1800 SSU).

Oil temperatures between  $-15/+70^{\circ}C$  (5 - 158°F).

Use hydraulic fluids which satisfy the recommended viscosity and oil temperatures given above.

#### Control of Contamination

Due caution must be paid to maintaining control over contamination of the hydraulic fluids which may otherwise lead to breakdowns and shorten the life of the valves. Please maintain the degree of contamination within NAS 1638-Grade 12. Use 25  $\mu$ m or finer line filter.

### Attachment

### Mounting Bolts

Valve	Socket Head Cap Screw			
Model Numbers	Japanese Std. "JIS" & European Design Std.	N. American Design Std.	Qty.	
UCF1G-01	$M6 \times 55$ Lg.	1/4-20 UNC × 2-1/4 Lg.	4	
UCF1G-03	M6 × 55 Lg.	1/4-20 UNC × 2-1/4 Lg.	4	
UCF2G-03	M6 × 55 Lg.	1/4-20 UNC × 2-1/4 Lg.	4	
UCF1G-04	M10 × 70 Lg.	3/8-16 UNC × 2-3/4 Lg.	4	
UCF2G-04	M10 $\times$ 70 Lg.	3/8-16 UNC × 2-3/4 Lg.	4	



### Feed Control Valves UCF1G-01 / 03 / 04 UCF2G-03 / 04

# FLOW CONTROLS

### Instructions

### Instructions

### • Allowable pressures at controlled flow outlet

If internal drain types of UCF1G-01 or 03 or UCF2G-03 are used, use them in metre-out circuits in order to limit the valve outlet pressure to the valves shown below. In addition, external drain types can also be used in metre-in circuits.

Model Numbers		Allowable Outlet Port Back Pres. MPa (PSI)
Internal	UCF1G-01-*	
Drain	UCF1G-03-*	0.3 (44)
Туре	UCF2G-03-*	
	UCF1G-01-*-E	
External	UCF1G-03-*-E	
Drain Type	UCF1G-04	14 (2030)
	UCF2G-03-*-E	
	UCF2G-04	

#### • Minimum required pressure difference

The minimum pressure differential between inlet and outlet port is required to obtain the optimum pressure compensation. It varies accordingly to the flow rate to be set. For details, refer to the performance curve.

### Spool push down level

Limit the spool push down level within the allowable maximum stroke range shown in the installation drawings.

### Allowable drain port back pressure

Limit to 0.1 MPa (15 PSI).

In addition, connect the drain pipe independently and directly to the tank. (This applies only to external drain types.)

### • Required Force for Spool Push Down

Model Numbers	Drain Type	Force N (lbs.)
UCF1G-01	Internal drain type	100 (22.5)
00110-01	External drain type	80 (18.0)
UCF1G-03	Internal drain type	170 (38.2)
	External drain type	90 (20.2)
UCF2G-03	Internal drain type	170 (38.2)
UCF2G-05	External drain type	130 (29.2)
UCF1G-04	UCF1G-04 External drain type	
UCF2G-04	External drain type	170 (38.2)

Note: The push down forces are with the maximum allowable pressure at the port concerned, which is controlled flow outlet "B" for internal drain types or the drain port for internal drain types.

### Line filter

To carry out flow adjustments by as small degree as 2 L/min(.53 U.S. GPM) or less, be sure to use a line filter, 10 or less, near the valve inlet.

#### Flow adjustment

#### [UCF1G-01, UCF\*G-03]

Loosen the locking screw and turn the flow adjustment dial clockwise for increase, and anti-clockwise for decrease.

The dial makes about 4 revolutions from zero to full flow and the valve opening is indicated on the revolution indicator.

After flow adjustment, tighten the locking screw.

### [UCF\*G-04]

Loosen the locking screw and turn the flow adjustment handle clockwise to increase, and anti-clockwise to decrease.

Open condition is indicated in digital-scale in built-in revolution indicator.

After flow adjustment, tighten the locking screw.





### Feed Control Valves UCF1G-01 / 03 / 04 UCF2G-03 / 04


# FLOW CONTROLS

**Performance Chracteristics** 


### Min. Required Pressure Difference
















### Feed Control Valves UCF1G-01 / 03


# Installation Drawings

# FLOW CONTROLS









# D



### Feed Control Valves UCF1G-01


# FLOW CONTROLS

**Spare Parts List** 

### UCF1G-01-\*-\*-\*-11/1190

# 

When making replacement of seals, please do it carefully after reading through the relevant instructions in the Operator's Manual.






# FLOW CONTROLS


**Spare Parts List** 

### UCF1G-03-\*-\*-10/1090

### 

When making replacement of seals, please do it carefully after reading through the relevant instructions in the Operator's Manual.





Section Y-Y

### List of Seals

Item	Name of Parts	Part Numbers	Qty.	Remarks
40	O-Ring	SO-NA-P4	1	
41	O-Ring	SO-NB-P10	1	
42	O-Ring	SO-NB-P10A	1	
43	O-Ring	SO-NA-P12	1	Included in Seal Kit Kit No:
44	O-Ring	SO-NB-P14	3	KITNO. KS-UCF1G-03-10
45	O-Ring	SO-NB-P16	1	
46	O-Ring	SO-NB-P18	1	
47	O-Ring	SO-NA-P6	1*	

 $\star$  Used only for external drain types (UCF1G-03- $\star$ -E-10).




# FLOW CONTROLS


**Spare Parts List** 

### UCF2G-03-\*-\*-10/1090

## 

When making replacement of seals, please do it carefully after reading through the relevant instructions in the Operator's Manual.





Y-Y

### List of Seal Kits

Model Numbers	Seal Kit Numbers
UCF2G-03-*-10*	KS-UCF2G-03-10
UCF2G-03-*-E-10*	KS-UCF2G-03-E-10

#### List of Seals

Item	Name of Parts	Part Numbers	Qty.
37	O-Ring	SO-NA-P4	2
38	O-Ring	SO-NB-P6	1*1
39	O-Ring	SO-NB-P10	2
40	O-Ring	SO-NB-P10A	1
41	O-Ring	SO-NA-P12	1
42	Back Up Ring	SO-BB-P12	1*2
43	O-Ring	SO-NB-P14	3
44	O-Ring	SO-NB-P16	1
45	O-Ring	SO-NB-P21	1

★ 1. Used only for external drain types (UCF2G-03-\*-<u>E</u>-10\*).

★ 2. Used only for internal drain types (UCF2G-03-\*-10\*).

Note: When ordering the seals, please specify the seal kit number from the table left.

